

## vtServer 3.2.0 Host Platform Compatibility List

This document provides a list of all hardware and components that are supported by this version of vtServer.

**Components that are not listed have not yet been tested; it does not necessarily mean that they will not work.** When in doubt about the support status of a hardware component, send email to [support@avtware.com](mailto:support@avtware.com)

AVTware cannot be held responsible for the fact that unverified products may prove not to work in practice, or that support has been dropped by the manufacturer of such product.

If you intend to run vtServer on a virtualized host system, please see the Virtual Machine section at the end of this document for a list of supported hypervisors.

### Systems

In general, any 64-bit X86 host should work, however there may be occasions where a specific chipset or on-board controller may not yet be included. When in doubt contact [support@avtware.com](mailto:support@avtware.com)

#### HP Server Platforms

*Gen8 and newer recommended*

HP Proliant: ML (tower), DL (rackmount) and BL (blade) models

#### Dell

PowerEdge Blade, Rackmount and Tower models

Note: The combination of Dell PowerEdge servers and SCSI adapter cards proves to be a problem and cannot be used. This can be an issue when you need to attach legacy tape devices.

Consult AVT or Vere when you are forced to use such a combination.

### Processors

*For all processors the following rule applies: **the higher the clock frequency, the better the virtualized performance.***

#### Intel

i5, i7; Xeon models 5500, 5600; E3, E5, E7

#### AMD

A6, A8, A10; Phenom II; Opteron 4000, 6000

## Storage Adapters

Many hardware brands offer hardware RAID controllers and software RAID. Software RAID is based on special drivers made by and dedicated to that specific hardware vendor or product set.

The software RAID functionality is not supported because it utilizes proprietary software that the vendor has not made available to be included in vtServer or any other product (i.e. VMware). The software RAID controllers may be used with vtServer only if the RAID feature is disabled, which eliminates hardware redundancy.

Hardware redundancy requires hardware RAID controllers or the use of storage on a SAN. Installation of vtServer software on SAN-based storage is supported in versions 2.10.2 and later.

Note: The combination of Dell PowerEdge servers and SCSI adapter cards proves to be a problem and cannot be used. This can be an issue when you need to attach legacy tape devices. Consult AVT or Vere when you are forced to use such a combination.

### Adaptec

AIC-7899P  
2020SA, 2410SA, 29160, 29320

### Dell

PERC H310, H330  
PERC H710, H710P, H730, H730P, H740P  
PERC H810, H810P, H830  
SPERC 8

### Emulex (FibreChannel) - All

#### HP

Microsemi SmartPQI controller (used in Gen10 systems)  
HP 412911  
HP SC11Xe SCSI HBA  
Smart Array 5300, 5312, 532, 5i  
Smart Array 6400, 6400 EM  
Smart Array 641, 642, 6i  
Smart Array E200, E200i  
Smart Array E500  
Smart Array P212, P220i, P222, P230i, P240ar, P244br  
Smart Array P400, P400i, P410, P410i, P411, P420, P420i, P421  
Smart Array P430 P430i, P431, P440, P440ar, P441  
Smart Array P530, P531, P600  
Smart Array P700m, P711m, P712m, P721, P731m, P741m  
Smart Array P800, P812, P822, P830, P830i, P831, P840  
Smart HBA H240, H240ar, H241, H244br, H420ar  
StorageWorks P1210m

#### Intel

82801ER (ICH5R) SATA

### Qlogic (FibreChannel) - All

#### Promise

PDC20318, R20378

## Ethernet Adapters

### 3COM

3c905, 3c940, 3c996, 3c980

### Allied Telesis

AT-2711FX-SC-901 Fiber Optic Ethernet adapter

### Broadcom

BCM5701, BCM5708, BCM5721, BCM5787

### D-Link

DFE-528TX, DFE-530TX, DFE-538TX

### Intel

E1000, Pro/100, Pro/1000  
82541GI/PI, 82546EB, 82566D, 82573L

### Realtek

RTL8139, RTL-8168, RTL8169

## Graphic Adapters

*Most standard graphics adapters are supported out of the box. When more advanced graphics features are needed, such as for the virtualization of a graphical workstation, adapters that use non-standard drivers may be required. A list of supported ATI and NVIDIA graphic adapters and the required drivers may be found on our web site at [avtware.com/support](http://avtware.com/support).*

*Note: Management of vtServer is performed using the system console or using a browser-based interface that can be accessed from any system on the network; graphics support on the vtServer host system is not required.*

### ASUS

EAX550, EAH4350, EAH5450, EAH5670

### AMD/ATI

Radeon, Rage XL

### Intel

HD2000, HD3000  
4500MHD, 850GM, 965GM

### Matrox

G550, P650

### Nvidia

GEFORCE, GRID, NFORCE  
NVS, QUADRO, TESLA

### VIA

KM400

## Serial Line Adapters

### Moxa

#### *2 port multiport board:*

CP-102U, CP-102UL, CP-102UF, CP-102E, CP-102EL  
CP-132U-I, CP-132UL, CP-132EL, CP-132EL-I  
CP-132, CP-132I, CP-132S, CP-132IS  
CI-132, CI-132I, CI-132IS, C102H, C102HI, C102HIS, C102P, CP-102, CP-102S

#### *4 port multiport board:*

CP-104EL  
CP-104UL, CP-104JU  
CP-134U, CP-134U-I  
C104H/PCI, C104HS/PCI  
CP-114, CP-114I, CP-114S, CP-114IS, CP-114UL, CP-114EL, CP-114EL-I  
C104H, C104HS  
CI-104J, CI-104JS  
CI-134, CI-134I, CI-134IS, C114HI, CT-114I, C104P  
POS-104UL  
CB-114  
CB-134I

#### *8 port multiport board:*

CP-118EL, CP-168EL  
CP-118U, CP-168U  
C168H/PCI, C168H, C168HS, C168P  
CB-108

**Digi** -- Most types

**USB Serial Line Adapters** – Most brands and types

## Virtual Machines

### Hyper-V

Yes; however, it does not support USB and requires a network license server (e.g. vtLicense)

### KVM

Yes.

### VMware

Yes; however, pre-version 5 did not support USB and requires a network license server (e.g. vtLicense)

### Xen Project Hypervisor

Yes.

*Users have experienced problems with some hypervisors, including VMware ESXi versions prior to 5.5, dropping USB devices dedicated to the vtServer host for the hardware license key. When this occurs, running virtual Alpha or VAX instances will be halted after the license time-out period (16 hours) is exceeded unless the license is served via a network license server in the interim.*

*We recommend the use of vtLicense or another network license server when running vtServer on a virtual host system to eliminate the risk of the hypervisor dropping the license device from the VM and to increase the flexibility of your virtual VAX and Alpha installation. Use of a network license server allows you to use the hypervisor's live host migration features (e.g., VMware vMotion) to move your virtual VAX and Alpha instances across physical hosts in the VM environment.*

## vtMonitor Management Console

*vtServer includes a browser-based graphical user interface (vtMonitor) that provides the capability to manage vtServer and the virtual Alpha and VAX configurations from any computer in the network with IP (http/https) access to the vtServer host.*

### **Supported browsers (use recent versions):**

- Mozilla Firefox
- Microsoft Internet Explorer
- Microsoft Edge
- Apple Safari
- Google Chrome